

PERMA COLOUR FLEXIBLE CRACK FILLER **PREPARATION AND USES**

USING A GRINDER WITH A SUITABLE BLADE, CUT DOWN APPROXIMATELY 10-20mm FOLLOWING THE CRACK FROM ITS ORIGIN TO ITS END.

THOROUGHLY ACID WASH AND WATERBLAST THE AREA TO ENSURE NO DUST OR LOOSE CONCRETE MATERIAL IS PRESENT.

ALLOW ENOUGH TIME TO DRY - CRACK CAN BE DAMP NOT WET.

**USE A MECHANICAL MIXER AND CLEAN WATER MIXING A SUFFICIENT AMOUNT OF PERMA COLOUR CRACK FILLER FOR ONE APPLICATION.
MIXING TIME SHOULD BE APPROX 5 MINS.**

MIX TO A CREAMY CONSISTENCY FOR APPLICATION, APPLYING FIRST COAT TO CRACKS USING A SMALL TROWEL OR SPATULA.

ALLOW TIME FOR MATERIAL TO SLUMP, APPROX. 30 MINS.

APPLY SECOND COAT IN THE SAME WAY, OVERFILLING THE CRACK.

ALLOW TO DRY THOROUGHLY, IF IN THE SHADE ALLOW TO DRY OVERNIGHT.

SAND OFF ALL EXCESS MATERIAL USING A TERRAZZO STONE OR SIMILAR.

NOTE: NEVER FILL DIRTY OR WATER FILLED CRACKS. NEVER TOP WITH FLO-CRETE UNTIL CURING TIME FOR CFC10 HAS ELAPSED. (APPROX 30 MINS. IN GOOD WARM DRYING CONDITIONS.)

THE INFORMATION PRESENTED IS BELIEVED TO BE ACCURATE. HOWEVER, NO GUARANTEE IS IMPLIED OR GIVEN, USERS SHOULD CONDUCT THEIR OWN TESTING TO DETERMINE THE SUITABILITY OF ANY PRODUCT FOR A PARTICULAR USE.